ResortLOCK
Remote Access Lock System

www.ResortLock.com

# LockState RL4000 Quick Operation Guide

**Failure to follow the exact procedure can result in erratic lock behavior.**

General Information

- Reset lock: press and hold reset button (below the batteries holder) for 10 seconds, red LED flash and beeps three times.
- Default master code: **123456**

Tips for a new setup

1. Change master code **(Default 123456)**
2. Set lock time
3. Enable auto lock /auto unlock function and set function time (if needed)
4. Add users

How to use the code/iButton

1. code: Enter code, #
2. iButton: Touch iButton reader
3. User iButton+code: Touch iButton reader, code, #
4. One time service code: Enter *, code, #

Set New or Change Master Code (and not delete existing user code)

| # | current or default mc | # | 11 | # | 1-9 digits new mc | # | 1-9 digits new mc | # |
|---|---|---|---|---|---|---|---|---|

Change Master Code (and delete all user code)

| # | current or default mc | # | 22 | # | 1-9 digits new mc | # | 1-9 digits new mc | # |
|---|---|---|---|---|---|---|---|---|

1. Set date / time

| # | mc | # | 88 | # | yymmddhhmm | # |
|---|---|---|---|---|---|---|

2. Enter one or more user code with no restriction (for multiple code, repeat highlight part)

| # | mc | # | 01 | # | 1-9 digits user code | # | # | # |
|---|---|---|---|---|---|---|---|---|

3. Enter one or more iButton key with no restriction (for multiple code, repeat highlight part)

| # | mc | # | 01 | # | iButton key | # | # |
|---|---|---|---|---|---|---|---|

4. Enter one or more iButton key + user Code with no restriction (for multiple code, repeat highlight part)

| # | mc | # | 01 | # | 1-9 digits user code | # | iButton key | # | # |
|---|---|---|---|---|---|---|---|---|---|

**5.** Enter one or more user code with time restriction (for multiple code, repeat highlight part)

| | | | | | | (beginning time) | | (ending time) | |
|---|---|---|---|---|---|---|---|---|---|
| # | mc | # | 01 | # | 1-9 digits user code | # | yymmddhhmm | # | yymmddhhmm | # |

6. Enter one or more iButton key with time restriction (for multiple code, repeat highlight part)

| | | | | | | (beginning time) | | (ending time) | |
|---|---|---|---|---|---|---|---|---|---|
| # | mc | # | 01 | # | iButton key | yymmddhhmm | # | yymmddhhmm | # |

7. Enter one or multiple ibutton + user codes with time restriction (for multiple, repeat highlight part)

| | | | | | | | | (beginning time) | | (ending time) | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| # | mc | # | 01 | # | 1-9 digits user code | # | iButton key | yymmddhhmm | # | yymmddhhmm | # |

8. Disable one or multiple user (using index) (for multiple user, repeat highlight part)

| # | mc | # | 02 | # | 1-3 digits index number | # |
|---|---|---|---|---|---|---|

9. Enable one or more user (using index) (for multiple user, repeat highlight part)

| # | mc | # | 03 | # | 1-3 digits index | # |
|---|---|---|---|---|---|---|

10. Enable/ disable Passage Mode

| # | mc | # | 15 | # |
|---|---|---|---|---|

2beeps: passage mode.
4 beeps: storehouse mode

11. Enable/ disable LED blink

| # | mc | # | 18 | # |
|---|---|---|---|---|

2beeps: blink off.
4 beeps: blink on

12. Enable daytime saving

| # | mc | # | 31 | # |
|---|---|---|---|---|

13. Disable daytime saving

| # | mc | # | 32 | # |
|---|---|---|---|---|

14. Add One Time Service codes (up to 10) (for multiple user, repeat highlight part)

| # | mc | # | 33 | # | 1-9 digits user code | # |
|---|---|---|---|---|---|---|

15. Delete one user or multiple users (for multiple user, repeat highlight part)

| # | mc | # | 44 | # | 1-3 digits index | # |
|---|---|---|---|---|---|---|

16. Delete one code/iButton user without index #

| # | mc | # | 46 | # | User code or touch ibutton | # |
|---|---|---|---|---|---|---|

17. Enable auto-unlock function

| # | mc | # | 64 | # |
|---|---|---|---|---|

18. Disable auto-unlock function

| # | mc | # | 65 | # |
|---|---|---|---|---|

19. Set automatically unlock time (Enable function 64first)

| # | mc | # | 63 | # | hhmm | # |
|---|---|---|---|---|---|---|

20. Enable auto-lock function

| # | mc | # | 67 | # |
|---|---|---|---|---|

21. Disable auto-lock function

| # | mc | # | 68 | # |
|---|---|---|---|---|

**22.** Set Automatically lock time (Enable function 67first)

| # | mc | # | 66 | # | hhmm | # |
|---|---|---|---|---|---|---|

23. Enable/Disable temporary lockout all the users

| # | mc | # | 99 | # | |
|---|---|---|---|---|---|

## Advanced Function

24. Set schedule for code user

| # | mc | # | 45 | # | 1-9 digits user code | # | 1-7 Schedule | hhmm | hhmm | # |
|---|---|---|---|---|---|---|---|---|---|---|

25. Set schedule for iButton user

| # | mc | # | 45 | # | IButton key | # | 1-7 Schedule | hhmm | hhmm | # |
|---|---|---|---|---|---|---|---|---|---|---|

For Example: to set schedule from 8:00AM to 5:00PM, Mon. to Friday

| # | mc | # | 45 | # | 1-9 digits user code | # | 12345 | 0800 | 1700 | # |
|---|---|---|---|---|---|---|---|---|---|---|